



STOPWATCH



USER MANUAL

ALARM TIME SETTING

1. In normal time mode, press A twice to activate this mode.
2. Press B to change the hour value.
3. Press C to select the minute and press B to change the minute value.
4. Press A to return to normal time mode.



NOTE:

1. To turn the alarm ON/OFF, press B and C at the same time.
2. The alarm will turn on automatically once you set the alarm time.
3. When the alarm is on
 - (1) It will last one minute without pressing any button then not sound again until the next day.
 - (2) When the alarm is sounding, press B to activate the snooze function and the alarm will start again after 5 minutes. It will sound up to one minute then not sound again until the next day.
 - (3) Press C to stop alarm.


HOURLY CHIME SETTING

1. In normal time mode, press and hold C with alarm time displayed.
2. Press A at the same time until all days of the week appear / disappear.



BATTERY REPLACEMENT

When the LCD becomes dim, replace with a new LR44 battery at once.



FEATURES

- Time / Calendar display
- Hour (12/24-hour format) minute second month date and day
- Stopwatch: 1/100 second for 30 minutes, 1 second up to 24 hours

FUNCTION KEYS

- A. MODE button:**
- Switch among normal time mode, stopwatch mode, alarm time setting mode and normal time setting mode.
- B. START/STOP button:**
- Toggle between normal time and month/date display.
- C. SPLIT/RESET button:**
- Toggle between normal time and alarm time display.

DISPLAY SYMBOLS

Normal Time Mode:

1. Day of the week
2. Hour
3. Minute
4. Second



Alarm Time Mode:

1. Alarm time
2. Alarm icon



STOPWATCH MODE

In normal time mode, press A once to activate this mode. Press C to reset the stopwatch to "0:0000" before using the stopwatch.

1. Accumulate elapsed time measurement: B-B-B-B-C



2. Split time measurement: B-C-C-B-C



3. Measurement between two competitors: B-C-B-C-C




NOTE:

1. Press A to return to the normal time mode.
2. 1/100 second stopwatch for 30 minutes, and 1 second stopwatch from 31st minutes up to 24 hours.

TIME / CALENDAR SETTING

1. In normal time mode, press A three times to activate time setting mode.
2. Press C to select the setting items. The sequence will be: Second>Minute>Hour>Date>Month>Day.
3. Press B to increase the setting value and change 12/24 hour format when setting the hour.
4. Press A to return to normal time mode.



NOTE:

1. Press B to add one minute when the second is more than or equal to 30 and reset it to 00 when the value is less than 30.